


26H



1.1995

Spare parts

Ersatzteile


Pièces détachées





Reserve onderdelen







Repuestos

Reservdelar

A



B**compl 531 00 29-28****C****D****E*****compl 531 00 29-42**

F**I*****compl 531 00 29-36****G****J*****compl 531 00 29-49****H****K**

MODEL NUMBER 26H

| PART NUMBER | SQUARE | NOTE | PART NUMBER | SQUARE | NOTE | PART NUMBER | SQUARE | NOTE | PART NUMBER | SQUARE | NOTE |
|--------------|--------|------|--------------|--------|------|--------------|--------|------|-------------|--------|------|
| 501 48 54-01 | D | | 531 00 29-31 | C | | 531 00 30-83 | A | | | | |
| 501 78 97-01 | E | | 531 00 29-32 | C | | 531 00 30-84 | A | | | | |
| 501 78 98-01 | E | | 531 00 29-33 | C | | 531 00 30-85 | A | | | | |
| 501 79 01-01 | E | | 531 00 29-34 | C | | 531 00 30-86 | A | | | | |
| 501 79 04-01 | E | | 531 00 29-35 | I | | 531 00 30-87 | A | | | | |
| 501 79 07-01 | J | | 531 00 29-36 | I | | 531 00 30-88 | A | | | | |
| 501 79 08-01 | J | | 531 00 29-37 | I | | 531 00 30-89 | A | | | | |
| 501 89 11-01 | E | | 531 00 29-38 | I | | 531 00 30-90 | A | | | | |
| 501 93 13-01 | J | | 531 00 29-39 | I | | 531 00 30-91 | A | | | | |
| 501 94 03-01 | A | | 531 00 29-40 | I | | 531 00 30-92 | A | | | | |
| | | | | | | | | | | | |
| 501 94 04-01 | A | | 531 00 29-41 | I | | 531 00 30-93 | A | | | | |
| 501 94 06-01 | A | | 531 00 29-42 | E | | 531 00 30-94 | A | | | | |
| 501 94 07-01 | A | | 531 00 29-43 | E | | 531 00 30-95 | A | | | | |
| 501 94 08-01 | A | | 531 00 29-44 | E | | 531 00 30-96 | A | | | | |
| 501 94 09-01 | A | | 531 00 29-45 | E | | 723 53 35-55 | A | | | | |
| 501 94 10-01 | A | | 531 00 29-46 | F | | 724 33 28-51 | A | | | | |
| 501 94 11-01 | A | | 531 00 29 47 | F | | 734 11 56-01 | A | | | | |
| 501 94 14-01 | A | | 531 00 29-48 | E | | 738 21 01-01 | A | | | | |
| 501 94 19-01 | A | | 531 00 29-49 | J | | 738 21 01 04 | A | | | | |
| 501 94 26-01 | K | | 531 00 29-50 | J | | | | | | | |
| | | | | | | | | | | | |
| 501 94 28-01 | K | | 531 00 29-51 | J | | | | | | | |
| 502 12 85-01 | A | | 531 00 29-52 | J | | | | | | | |
| 503 02 02-01 | G | | 531 00 29-53 | J | | | | | | | |
| 503 20 12-01 | A | | 531 00 29-54 | J | | | | | | | |
| 503 20 12-07 | A | | 531 00 29-55 | J | | | | | | | |
| 503 20 51-01 | K | | 531 00 29-56 | J | | | | | | | |
| 503 21 48-01 | D | | 531 00 29-57 | J | | | | | | | |
| 503 21 83-14 | C | | 531 00 29-58 | J | | | | | | | |
| 503 21 83-18 | DF | | 531 00 29-59 | J | | | | | | | |
| 503 21 83-19 | C | | 531 00 29-60 | J | | | | | | | |
| | | | | | | | | | | | |
| 503 21 83-20 | H | | 531 00 29-61 | H | | | | | | | |
| 503 21 83-26 | F | | 531 00 29-62 | A | | | | | | | |
| 503 21 83-31 | A | | 531 00 29-63 | A | | | | | | | |
| 503 21 83-39 | J | | 531 00 29-64 | A | | | | | | | |
| 503 22 02-01 | G | | 531 00 29-65 | A | | | | | | | |
| 503 22 20-01 | I | | 531 00 29-70 | A | | | | | | | |
| 503 22 23-03 | A | | 531 00 29-71 | A | | | | | | | |
| 503 23 50-11 | D | | 531 00 29-72 | A | | | | | | | |
| 503 25 01-02 | G | | 531 00 29-73 | A | | | | | | | |
| 503 25 31-01 | G | | 531 00 29-75 | A | | | | | | | |
| | | | | | | | | | | | |
| 503 26 05-03 | H | | 531 00 29-77 | A | | | | | | | |
| 503 27 11-01 | G | | 531 00 29-78 | A | | | | | | | |
| 505 52 01-13 | B | | 531 00 29-79 | K | | | | | | | |
| 505 52 01-25 | B | | 531 00 29-80 | B | | | | | | | |
| 505 52 01-27 | B | | 531 00 29-81 | B | | | | | | | |
| 531 00 25-66 | B | | 531 00 29-82 | B | | | | | | | |
| 531 00 25-67 | J | | 531 00 29-83 | B | | | | | | | |
| 531 00 29-00 | B | | 531 00 29-84 | B | | | | | | | |
| 531 00 29-08 | H | | 531 00 29-85 | B | | | | | | | |
| 531 00 29-09 | H | | 531 00 29-86 | B | | | | | | | |
| | | | | | | | | | | | |
| 531 00 29-10 | H | | 531 00 29-87 | B | | | | | | | |
| 531 00 29-11 | H | | 531 00 29-88 | B | | | | | | | |
| 531 00 29-12 | H | | 531 00 29-89 | B | | | | | | | |
| 531 00 29-13 | F | | 531 00 29-90 | B | | | | | | | |
| 531 00 29-14 | F | | 531 00 29-91 | B | | | | | | | |
| 531 00 29-15 | F | | 531 00 29-92 | B | | | | | | | |
| 531 00 29-16 | F | | 531 00 29-93 | B | | | | | | | |
| 531 00 29-17 | F | | 531 00 29-94 | B | | | | | | | |
| 531 00 29-18 | G | | 531 00 29-95 | B | | | | | | | |
| 531 00 29-19 | G | | 531 00 29-96 | B | | | | | | | |
| | | | | | | | | | | | |
| 531 00 29-20 | G | | 531 00 29-97 | B | | | | | | | |
| 531 00 29-21 | D | | 531 00 29-98 | B | | | | | | | |
| 531 00 29-22 | D | | 531 00 29-99 | B | | | | | | | |
| 531 00 29-23 | D | | 531 00 30-75 | A | | | | | | | |
| 531 00 29-24 | D | | 531 00 30-76 | A | | | | | | | |
| 531 00 29-25 | C | | 531 00 30-77 | A | | | | | | | |
| 531 00 29-26 | C | | 531 00 30-78 | A | | | | | | | |
| 531 00 29-27 | C | | 531 00 30-79 | A | | | | | | | |
| 531 00 29-28 | BC | | 531 00 30-80 | A | | | | | | | |
| 531 00 29-29 | C | | 531 00 30-81 | A | | | | | | | |
| | | | | | | | | | | | |
| 531 00 29-30 | C | | 531 00 30-82 | A | | | | | | | |