

# T350, 350R, 500 R

**Spare parts**

**Ersatzteile**

**Pièces détachées**

**Reserve onderdelen**

**Repuestos**

**Reservdelar**

Replaces

Ersetzt


Remplace

Vervangt

Reemplaza

Ersätter

106 23 12-66



## T350 / 350R / 500R

1	<b>519 65 34-05</b>	41	519 65 30-07	80	519 65 30-46
2	519 65 02-81	42	519 65 30-43	81	732 25 22-01
3	519 65 30-58	43	519 65 30-41	82	<b>519 65 34-25</b>
4	519 65 30-59	44	519 65 30-42	83	<b>519 65 34-26</b>
5	<b>519 65 34-06</b>	45	519 65 33-91	84	519 65 02-60
6	<b>519 65 34-07</b>	46	519 65 30-72	85	519 65 30-00
7	<b>519 65 34-08</b>	47	519 65 30-67	86	<b>519 65 34-60</b>
8	<b>519 65 34-09</b>	48	519 65 30-10	87	519 65 12-10
9	519 65 30-90	49	519 65 30-45	88	519 65 12-20
10	519 65 30-52	50	519 65 30-57	89	519 65 30-78
11	<b>519 65 34-10</b>	51	519 65 30-06	90	519 65 30-44
12	519 65 30-47	52	519 65 30-95	91	<b>519 65 34-61</b>
13	519 65 30-17	53	519 65 30-94	92	519 65 30-85
14	519 65 30-68	54	519 65 30-65	93	519 65 31-01
15	519 65 12-90	55	519 65 30-54	94	519 65 30-84
16	728 69 23-00	56	519 65 30-71	95	
17	<b>519 65 34-11</b>	57	519 65 30-86	96	
18	<b>519 65 34-12</b>	58	<b>519 65 34-16</b>	97	519 65 30-96
19	519 00 64-25	59	<b>519 65 34-17</b>	98	519 65 30-28
20	<b>519 65 34-47</b>	60	<b>519 65 34-18</b>	99	519 65 30-29
21	<b>519 65 34-13</b>	60a	<b>519 65 34-19</b>	100	519 65 30-01
22	519 65 30-21	61	732 25 20-01	101	<b>519 65 30-92</b>
23	519 65 31-02	62	725 25 50-51	102	519 65 33-60
24	<b>519 65 34-14</b>	63	<b>519 65 34-32</b>	103	519 65 31-03
25	<b>519 65 34-15</b>	64	516 83 65-15	104	<b>519 65 34-62</b>
26	<b>519 65 34-49</b>	65	<b>519 65 34-59</b>	105	<b>519 65 34-30</b>
27	<b>519 65 34-50</b>	66	519 64 94-71	106	<b>519 65 34-33</b>
28	<b>519 65 34-51</b>	67	519 65 30-80	107	<b>519 65 34-63</b>
29	<b>519 65 34-52</b>	68	519 65 30-70	108	<b>519 65 34-48</b>
30	<b>519 65 34-53</b>	69	519 65 30-49	109	<b>519 65 34-37</b>
31	<b>519 65 34-54</b>	70	519 65 30-66	110	<b>519 65 34-64</b>
32	<b>519 65 34-55</b>	71	519 65 30-91	111	<b>519 65 34-65</b>
33	<b>519 65 34-56</b>	72	519 65 30-55	112	<b>519 65 34-66</b>
34	<b>519 65 34-57</b>	73	<b>519 65 34-20</b>	113	<b>519 65 34-27</b>
35	519 65 11-60	74	519 65 30-51		
36	519 00 64-71	75	519 65 30-60		
37	<b>519 65 34-58</b>	76	<b>519 65 34-21</b>		
38	519 65 30-09	77	<b>519 65 34-22</b>		
39	519 65 30-53	78	<b>519 65 34-23</b>		
40	519 00 26-31	79	<b>519 65 34-24</b>		

Correction:

Pos. 101 519 65 30-93