

# R152 SVSW

**Spare parts**

**Ersatzteile**

**Pièces détachées**

**Reserve onderdelen**

**Repuestos**

**Reservdelar**

---


## **ILLUSTRATED PARTS LIST**

**MODEL NUMBER R 152SVSW**

**PRODUCT NUMBER 961 41 00-64**

**MFG. ID. NUMBER 96141006404**

# ROTARY LAWN MOWER - - MODEL NUMBER R 152SVSW (96141006404) PRODUCT NUMBER 961 41 00-64




# ROTARY LAWN MOWER - - MODEL NUMBER R 152SVSW (96141006404) PRODUCT NUMBER 961 41 00-64

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	532 19 05-82	Handle, Grassbag, Rear	34	532 19 06-19	Adjustment Bracket, Lower Handle, LH
2	532 06 53-22	Hairpin Cotter	35	532 18 23-98	Knob, Star
3	532 18 34-83	Rod, Rear Handle, Grassbag	36	532 19 41-87	Bolt, Shoulder
4	532 40 18-98	Grassbag	37	532 18 59-96	Deflector, Discharge
5	532 18 85-06	Frame, Grassbag	38	532 19 06-21	Adjustment Bracket, Lower Handle, RH
6	812 00 00-14	E-Ring	39	532 19 15-74	Bolt, Handle
7	532 19 05-81	Door, Grassbag	40	532 06 64-26	Wire Tie
8	532 18 34-79	Rod, Pivot	42	532 18 70-96	Handle Assembly, Lower
9	872 14 04-05	Bolt, Carriage 1/4-20	43	532 18 62-98	Bail, Control
10	873 80 04-00	Nut, Hex, Nylock 1/4-20	44	532 18 27-48	Grip, Foam
11	532 19 06-92	Foot Guard	45	532 18 62-96	Handle Assembly, Upper (Includes Foam Grip)
15	532 15 04-06	Bolt, Engine Mounting	46	532 40 88-85	Cable, Engine Zone Control
16	532 41 50-76	Blade, 21"	47	532 75 06-34	Screw
17	532 85 10-74	Washer, Hardened	48	532 12 52-03	Bracket, Upstop
18	532 85 02-63	Washer, Lock	49	532 13 20-04	Nut, Hex
19	532 19 17-60	Bolt, Hex Head, Grade 8	50	532 18 85-01	Rope Guide
20	532 18 67-66	Adapter, Blade	51	532 42 46-78	Kit, Housing
21	532 19 05-16	Debris Shield	52	- - -	Engine, Briggs & Stratton, Model Number 100602-2980-EA (Order parts from Engine Manufacturer)
22	817 60 04-06	Screw, Hex Head, Serrated	53	532 40 18-96	Grassbag Assembly, Complete
23	532 18 36-09	Mounting Bracket, Mulcher Door	54	532 18 90-14	Discharge Chute Assembly, Complete
24	532 19 17-30	Nut, Hex	55	532 19 41-92	Stud, Shoulder T45
25	532 18 34-45	Rod, Hinge	56	812 00 00-58	E-Ring
26	532 18 34-46	Spring, Mulcher Door	84	532 40 01-00	Locknut, Hex
27	532 18 21-66	Decal, Danger	85	532 85 02-63	Washer, Lock 3/8
28	532 19 05-15	Mulcher Door	86	872 11 04-07	Bolt, Carriage 1/4-20 x 7/8
29	532 18 34-47	Knob	- -	532 18 21-34	Decal, Warning (not shown)
30	532 19 05-80	Door, Discharge Chute	- -	532 41 79-39	Operator's Manual, European
31	532 18 34-78	Spring, Door, Discharge Chute	- -	532 41 79-40	Operator's Manual, Scandinavian
32	532 18 34-45	Rod, Door, Discharge Chute	- -	532 41 79-41	Operator's Manual, East Bloc
33	532 19 05-78	Discharge Chute, Plastic	- -	532 41 79-42	Operator's Manual, Baltic

**NOTE:** All component dimensions given in U.S. inches. 1 inch = 25.4 mm. **IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your lawn mower and void your warranty.

# ROTARY LAWN MOWER - - MODEL NUMBER R 152SVSW (96141006404) PRODUCT NUMBER 961 41 00-64



# **ROTARY LAWN MOWER - - MODEL NUMBER R 152SVSW (96141006404) PRODUCT NUMBER 961 41 00-64**

KEY NO.	PART NO.	DESCRIPTION
1	532 42 56-65	Drive Control Assembly, Complete
2	532 41 16-73	Cover, Drive Control, Top
3	532 18 73-53	Pulley, Drive Control
4	532 42 56-62	Lever, Drive Control
5	532 41 16-64	Cover, Drive Control, Bottom
6	532 18 16-98	Screw, Torx Head #8-5/8
7	532 40 07-23	Bracket, Mounting, Drive Control
9	532 19 70-11	Cable, Drive Control
10	532 41 69-63	Cover Assembly, Drive
11	532 19 41-88	Screw
12	812 00 00-12	Ring, Retaining
13	532 08 86-52	Screw
14	532 40 80-27	Bearing / Axle Support
15	532 41 92-11	Gear Case Assembly, Complete
16	532 40 65-58	Spring, Return
17	532 40 80-05	Belt Keeper
18	532 16 34-09	Screw
19	532 19 40-18	Pulley, Drive
22	532 19 37-91	Pulley Assembly, V-Groove
23	532 18 81-52	O-Ring
24	532 40 91-49	Nut, Hex, Flangelock
25	873 93 05-00	Nut, Hex, Lock
26	532 41 67-36	Idler Arm
27	532 16 60-43	Pulley, Idler
28	532 16 08-29	Bolt, Hex Head, Shoulder
29	817 06 04-10	Screw 1/4-20 x 1/16
30	532 18 34-57	Cover, Dust, Wheel
31	532 08 83-48	Washer, Flat 3/8
32	532 19 26-22	Wheel Assembly, Rear 9 x 2-1/4

KEY NO.	PART NO.	DESCRIPTION
33	532 40 91-48	Nut, Hex
34	532 18 34-42	Hubcap
35	532 42 52-42	Knob, Star
37	532 40 48-45	Pawl
38	812 00 00-58	E-Ring
39	532 40 38-49	Pinion
43	532 19 05-20	Lever, Selector, Wheel Height, Rear
44	532 16 96-75	Clip, Retainer
45	532 18 50-51	Spring
46	532 18 50-54	Rod, Lock
47	532 18 72-47	Nut, Hex, Flangelock
48	532 18 89-06	Washer, Flat 1/2
49	532 19 59-96	Bushing
50	532 40 80-31	Belt, Drive
53	532 41 67-40	Rear Axle Assembly
55	532 42 42-45	Decal, Drive Control
57	532 41 70-63	Bracket, Caster Wheel, LH
58	532 18 72-48	Wing Nut 5/16-18
59	532 18 51-11	Spacer
60	532 19 22-34	Wheel Assembly, Front 9 x 2-1/4
61	872 27 05-28	Bolt, Carriage 5/16-18 x 3-1/2
62	532 18 74-74	Bolt, Carriage 5/16-18 x 7/8
63	532 18 84-75	Strap, Front
64	532 41 40-70	Support Tube Assembly, LH
65	532 41 70-64	Bracket, Caster Wheel, RH
66	532 41 40-69	Support Tube Assembly, RH
67	532 18 75-55	Bolt, Carriage 5/16-18 x 5/8
68	532 18 72-63	Nut, Hex 5/16
69	532 75 10-68	Bearing, Ball (Wheel)

**NOTE:** All component dimensions given in U.S. inches. 1 inch = 25.4 mm. **IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your lawn mower and void your warranty.